PARTS LIST

for

KitchenAid® 7-CUP FOOD PROCESSOR

MODELS:

KFP720WH2 (White)
KFP720ER2 (Empire Red)
KFP720BU2 (Cobalt Blue)
KFP720OB2 (Onyx Black)
KFP720BW2 (Blue Willow)
4KFP720WH2 (White)
4KFP720ER2 (Empire Red)
4KFP720BU2 (Cobalt Blue)

4KFP720OB2 (Onyx Black)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID ST. JOSEPH MICHIGAN 49085

MOTOR AND HOUSING PARTS

FOR MODELS: KFP720_ _2, 4KFP720_ _2



MOTOR AND HOUSING PARTS

FOR MODELS: KFP720_ _2, 4KFP720_ _2

Illus. No.	Part No.	DESCRIPTION
1	8212299	Literature Parts Use & Care Guide
2	8212317 8211816	Trilingual Repair Parts List Sleeve, Motor Shaft
3 4	8211817	Seal, Oil Housing, Motor
·	8211805 8211807 8211808 8211809 8212297	White Empire Red Cobalt Blue Onyx Black Blue Willow
5 6 7 8	8211610 8211871 8212318 8212319	Clamp, Cable Screw, Clamp Motor Grommet, Motor
9	8211801 8211802 8211803 8211804 8212296	Base, Housing White Empire Red Cobalt Blue Onyx Black Blue Willow
10	8212298 8212311 8212312 8212313 8212310	Cover, Screw White Empire Red Cobalt Blue Onyx Black Blue Willow
11	8211811	Screw, Motor Locking
12 13	8211878 8211884	Cover, Switch Bezel, Switch Panel
14 15 16	8211887 8211870 8211812	Seal, Switch Panel Screw, Torx Screw, Switch Panel
17 18 19	8211876 8211608 8211879	Nameplate Capacitor Relay & Switch Assembly
20 21	8211772 8211885 8211886	Foot, Black Cord, Power Black White

ATTACHMENT PARTS

FOR MODELS: KFP720__2, 4KFP720__2

